




Gebrauchsanweisung

51 4935
 (D,I,SF,N,S)
 51 4946
 (D,GB,GR))


Aufstellanweisung


51 4750
 (D,GB,F,I,NL,E)
 51 4934
 (D,I,SF,N,S)

Programmtabelle

51 4936
 (D,I,SF,N,S)
 51 4947
 (GR)
 51 4840
 (D,GB)


- 1) 27 3647
 Blende kompl.
 2) 03 2288
 3) 05 9694





- 1) 04 5561
2) 01 4687
3) 02 5345
4) 08 0451
Set

Zubehör:
Bodenbefestigung
WX 9756
Wäsche-Top
WZ 10120



- 1) 04 2309
2) 02 5350
3) 27 3073
15 5272
Triac-Motorleistung

