





51 0772/00
 D1,D2,CH1,F1
 51 1174/00
 F2
 (D,GB,F,I,NL,DK,N,S,SF,E,P)
 Gebrauchsanweisung

1) 05 0642/08
 kompl.

2) 08 0912/04
 D1, CH1, F1
 08 1399/04
 F2
 bis FD 6211
 08 1630/02
 D1,D2,CH1,F1
 08 1634/02
 F2
 ab FD 6212



TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Necchi	Matsushita		
Typ/Type		M 5 J	FN 73 F 13 S		
Förderleistung/Delivery/Débit		V 920	V 1310		
Anlaufstrom/Starting current/Cour. de démarrage		A 9,2	8,0		
Widerstand/Resistance/Résistance		Ω 16,6	11,6		
		Hi/aux Ω 38,7	60,6		
Temp.-Regler/Thermostat		Ranco			
Typ/Type		A 54			
Reglerstellung/Position		kalt warm			
Schaltwerte/Switching values/		„ein“ °C - 24 - 18			
Valeurs de commutation		„aus“ - 31 - 24			
		(„abtauen“ od.) „alarm“ - 19 - 14			
Füllmenge/Fill.quantity/Charge		R12 g 185	165		
Anschlußwert/Conn.load/Puiss. connectée		W 120			
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance		Ω			
Leistung/Power/Puissance		W			
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance		Ω			
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance		Ω			
Spannung/Voltage/Tension		V			

Pos.	D1, CH1, F1	D2, F2		
	Necchi	Matsushita		
1	14 0119/45	14 0104/45		
2	05 1252/09	02 1733/09		
3	05 1253/09	02 1734/09		
4	04 9990/05	05 1289/14		
5				
6	04 9991/01	05 1289/14		
7	04 9996/01	02 1735/01/2		
8				
9	01 3486/01			
10				
11				
12				
13				
14				