


Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
		ELEKTRISCHE TEILE	ELECTRICAL PARTS PIECES ELECTRIQUE
	75 4492	Fernbedienung kpl.	remote control cpl. télécommande cpl.
	75 5773	Chassisplatte kpl.	chassis panel c. i. principal
	73 5472	Lithium-Batterie	Lithium-battery Lithium-batterie
	75 5774	Kopfverstärker	head amplifier video ampli de tetes video
	75 4913	Tuner	tuner
	75 6523	Modulator	modulator modulateur
	75 5772	Bedieneinheit kpl.	jeystick unit cpl. unite de commande
	75 5775	Floureszenzanzeige	fluoresc. indic. panel affich. fluorescent.
	73 3142	Tipptaste (8 x)	push button touche
	75 5430	Netzteil kpl.	mains part cpl. alimentation cpl.
TR1	75 5431	Wandlertrafo	transformer transfo
OK1380	73 4350	Optokoppler	optocoupler coupleur-opto

Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
			
CIC130	73 5474	M74LS373	
IC145	73 4361	PCF8583	
IC165	72 3039	TL082	
IC180	73 5475	SDA5642	
IC200	73 6334	27128-250NS/20	
CIC230	73 3137	SDA2087	
IC305	73 5477	AN3824K	
IC322	73 5478	PU42C26	
IC340	73 4384	AN3814K	
IC360	73 5074	TDA2440-3	
IC365	73 2958	TDA2148	
IC390	73 4170	TBA120T	
IC410	73 2290	U4443B	
IC445	73 5832	ZTK9.0	
IC480	73 4372	TDA5652	
CIC570	73 5479	AN3231	
IC635	73 4554	MSM6965-3RS	
IC820,830	73 6332	AN6308	
IC880	73 6333	TDA4725	
IC890	73 5480	TA8644	
IC980	73 5481	74HCOON	
IC1005	73 4306	SBX1494-01 (IR)	
IC1010	73 3145	UPD7537	
IC1130	73 1085	AN3313	
IC1315	73 5482	TDA4605	
IC1383	73 4353	TL431CLP	
IC1430	73 5483	L455	
IC1501	73 4272	ON2170	
IC1502	73 4272	ON2170	
IC2161	73 6554	SDA3202/2	
			
T113	73 3231	BC369G	
CT115	73 0791	BC848C	
T118	73 3231	BC369G	
CT120,153, 170,226,230, 245,255,258	73 0791	BC848C	
CT240	73 0790	BC848B	
T270	73 2803	BC875/877/879	
CT285,330	73 0791	BC848C	
CT333	73 0792	BC858B	
CT372,380, 389	73 0790	BC858B	
T391	73 2960	BF414	
CT415,420, 424	73 0790	BC848B	
T435	73 3231	BC369G	
CT440,449	73 0791	BC848C	

Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
	53 0551	Gebrauchsanweisung Service-Druckschrift	instruction manual instruction d'emploi service-booklet brochure service

Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
			
CT455	73 3452	BC850C	
T466	73 3231	BC369G	
CT498	73 3233	BC857B	
CT500,501	73 5484	BC817-25	
CT505	73 6906	BC848B	
T506	72 3397	BC327-40	
T515	71 1566	BC327-25	
CT553,558, 575	73 6904	BC848	
T578	72 4287	BC328-40	
CT585	73 6905	BC858	
T590	72 4287	BC328-40	
CT615,650	73 6904	BC848	
CT655	73 6905	BC858	
CT720	73 6904	BC848	
CT722	73 6905	BC858	
T745	72 4287	BC328-40	
CT775,850	73 6905	BC858	
CT780,857	73 6904	BC848	
CT783,808, 838	73 6904	BC848	
BC835,841	73 6905	BC848	
CT865,875	73 6904	BC848	
CT885,843, 848	73 2288	BFS20	
CT887,898	73 6904	BC848	
CT899	73 2288	BFS20	
CT914,935, 945,960,970, 903,910,912	73 6904	BC848	
CT940	73 6911	BSV52	
CT962,925	73 6905	BC858	
CT965	73 6904	BC848	
CT990	73 6905	BC858	
CT1115,1118	73 5486	BC818-40	
CT1140,1155	73 6904	BC848	
CT1157	73 6905	BC858	
CT1165	73 6904	BC848	
CT1170	73 6905	BC858	
CT1172	73 2288	BFS20	
CT1176	73 6904	BC848	
CT1185	73 6905	BC858	
T1193	71 1947	BC338-40	
CT1200	73 2288	BFS20	
CT1227	73 6904	BC848	
T1335	73 5487	BUZ80	

Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
CD114,122, 125	73 3234	 LL101A,B,C	
CD130,131, 135,146,148, 170,175,176, 400	70 6829	1N4148	
D280	70 8179	1N4001	
CD351	73 6335	B619A/BB730	
CD405	73 6336	10B 0.5W	
CD425,427	73 6337	BA 582	
D445	73 5832	ZTK9.0	
D578	70 9863	1N4004	
CD744,864, 914,975,978, 812,828	73 4366	RLS245	
D1003	73 3147	ZD11C	
CD1191	73 4364	RLS135R-OHM	
GL1360	73 2778	SKB380	
D1307,1328	73 5488	BYT52D	
D1337,1338, 1397,1405, 1410	73 5489	BYT52M	
D1400	73 3147	ZD12	
D1415,1425	73 5490	BYV28/200	
Q145	72 7701	 32.768KHz	
Q250	73 1712	12.0MHz	
Q925	72 7719	4.433619MHz	
	73 5472	 Lithium Batterie	Lithium-battery Lithium-batterie
C145,952	73 5492	 4.5...20PF	
C518	73 4950	0.01µF/100V	
C905	73 4949	62pF 2%	
C428	73 6338	7.5 ... 50PF	
C1350	73 5493		
C1352	72 5681		
C1353	72 5681		
C1355	73 5493		
C1363	73 6286	47µF 385V	
C1365	72 5681		


Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
L204 L205 L373 L385 L391 L394 L410,420 L415,847 L490 L510 L520 L712 L713 L725 L740,742, 745,747,857 L836 L841 L842,849 L853 L859 L902 L905,892 L915 L917 L960 L940 DR1350 DR1355 L1408 L1420	73 4954 72 8230 73 5494 73 5495 73 6347 73 6348 73 5494 73 5497 72 2973 73 6349 73 3919 73 5498 73 5499 73 5500 72 7746 73 6350 73 6351 73 0287 73 6353 72 4961 73 5501 72 4908 72 7708 72 4920 73 6356 72 4908 73 6243 73 2783 72 8230 72 8267	 6,8µH 33µH 68µH 56µH 82µH 6,8µH 20µH  Wandlertrafo 	
TR1	75 5431		transformer/transfo
F353 F355,358 F360,361 F367 F385,390 F397 F410 F625 F652 F680 F880 F905 F930 F970	73 5485 73 6346 73 6345 73 6344 73 2204 73 5485 73 4955 73 3126 73 5332 73 3128 73 6341 73 6340 73 8227 73 0298		

Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
OK1380	73 4350	 Optokoppler	optocoupler coupleur-opto
	73 4341	Optokoppler/Bandanfang	Photo holder (R) unit coupleur-opto
	73 4342	Optokoppler/Bandende	Photo holder (L) unit coupleur-opto fin de bande
	75 5020	Wickelsensorpl. kpl.	winding-sensor cpl. senseur de bobinage cpl.
R285	73 4381	 47 Ohm	
R508	73 4373	33 Ohm	
R1328,1397, 1405,1415, 1425	73 0296	4.7 Ohm	
R1395	73 4227	0.22 Ohm	
R377	73 3165	 4.7 KOhm	
R400	73 6339	33 KOhm	
R401	73 2490	47 KOhm	
R503	73 1582	100 KOhm	
R605	73 3165	4.7 Kohm	
R660	73 3164	1 KOhm	
R695	73 3132	10 KOhm	
R735	73 3165	4.7 KOhm	
R752	73 3132	10 KOhm	
R765,905	73 3164	1 KOhm	
R770	73 3131	2.2 KOhm	
R785,790	73 3165	4.7 KOhm	
R795	73 3132	10 KOhm	
R800,865	73 3131	2.2 KOhm	
R925	73 3165	4.7 KOhm	
R920	73 3133	500 KOhm	
R987	73 3132	10 KOhm	
R1388	73 3164	1 KOhm	
R1611	73 3132	10 KOhm	
R1655	73 3164	1 KOhm	
R278	73 4951	 PTC1.8 Ohm	

SIEMENS

FM602S4FF


VIDEOGERÄTE
VIDEO-CASS-RECORDER
Video Equipments
Video cartridge recorder
Equipements Video
Enregistreur cassette video



SIEMENS

FM602S4FF

VIDEOGERÄTE
VIDEO-CASS-RECORDER
Video Equipments
Video cartridge recorder
Equipements Video
Enregistreur cassette video



°) 73 4314/02 Satz Federn
set springs
jeu ressorts

*) Unterlegscheiben:

73 5496 0,13 mm
73 5323 0,25 mm
73 4942 0,50 mm

+) Massefeder
(Funktionsblockade)

73 6330

