




Gebrauchsanweisung

51 5057

(D,GB,F,I,NL)

51 5284

(D,I,F,S,DK)

51 5288

(D,I,F,S,N)

Aufstellanweisung

51 4930

(D,NL,F,E,GB,I)

51 5286

(D,I,F,S,DK)

1) 27 3868

Blende kompl.

2) 02 8154

3) 03 0441 1)

Zubehör:

Unterbauszubehör

WX9752

Verlängerung der Arbeit-
platte


WZ10040


Verbindungssätze für

Wasch/Trockensäule


WZ20030

WZ20090





- 1) 03 0055
links
03 0054
rechts
- 2) 03 0052
rechts
03 0051
links



- 1) 02 1439
- 2) 04 6400

