


VS71138/02-D1,schwarz
VS71138/03-D2,schwarz
VS71143II/03-I1,schwarz
VS71143II/02-I2,schwarz

VS71143II/05-I3,schwarz
VS71138/05-D3,schwarz
VS71158/05-D4,tief-schwarz
VS71158/06-D5,tief-schwarz



Gebrauchsanweisungen

51 5661
D1,D2,D3
(D)
51 5552
I1,I2,I3
(D,GB,F,I,NL,DK,N,S,SF
E,P,GR)
51 6643
D4,D5
(D,GB,NL,F,I,E,P,GR,DK,
S,N,SF)

Zubehör:

Turbo-Universal-Bürste
VZ 470900
schwarz


Heizkörperbürste
VZ 0683
schwarz


Möbelpinsel
VX 0773
schwarz

1) 05 5798
D1,D2,D3
03 1601
I1,I2,I3,D4,D5

2) 46 0123
D1,D2,I1,I2,I3,D3
46 0378
D4,D5

3) 03 2798
D1,D2,D3,D4,D5
05 9200
I1,I2,I3





02 7109



08 0857



02 9169




45 0759


schwarz
46 0138
D4,D5
kompl.



28 7684



46 0097
schwarz
46 0380
schwarz
D4,D5



45 0140



46 0098
schwarz
46 0381
schwarz
D4,D5