



VIDEOCORD

FM 328 7/9


 Ausgabe: Dezember 1983
 Issue: Dezember 1983
 Edition: Decembre 1983

Pos. Item	Ident.-Nr. Ident.No.	Ersatzteil Spare part	Pckg. Qty. Pckg.	PG Price Gp.	Pos. Item	Ident.-Nr. Ident.No.	Ersatzteil Spare part	Pckg. Qty. Pckg.	PG Price Gp.
Pos.	N ^o d'ident.	Piece de rechange	Quant. Emb.	cat. de prix	Pos.	N ^o d'ident.	Piece de rechange	Quant. Emb.	cat. de prix
FUNKTIONSEINHEITEN FUNCTION UNITS ENSEMBLES FONCTIONNELS					Module/Modules				
	75 2445	Bedieneinheit kpl. operating unit ensemble de commande				75 2452	Chroma		
	75 2446	Ablaufsteuerung operating control contrôle de operation				75 2453	Video (Y) -video/video		
	75 2450	VCR-Kopfrad VCR-head wheel poulie à tête (VCR)				75 2454	Servo/DTF		
	75 2451	Kopfverstärker head amplifier amplificateur de tête				75 2455	Ton/sound/son		
	75 2211	Fernbedienung remote control telecommande				75 2119	Netzteil power unit bloc secteur		
	75 3639	VPS - Adapter				75 2120	Modulator/KT Ausführung I		
	-	Camera FB - Adapter FZ4241				75 3331	Ausführung II		
	75 2210	IR-Empfänger IR-Receiver FZ4243				75 2121	Tuner/ZF		
	75 2212	Pal-Secam FZ4248				75 2456	PAL-SECAM-Decoder f. FM 328 9		
						75 2471	Video (Y+ Chroma)-Modul		


SIEMENS

Pos.	Best.-Nr.	Gegenstand	Pckg.	PG	Pos.	Best.-Nr.	Gegenstand	Pckg.	PG
Item	Code No.	Part	Qty.	Price	Item	Code No.	Part	Qty.	Price
			Pckg.	Gp.				Pckg.	Gp.
Pos.	Ref. de	Objet	Quant.	cat.	Pos.	Ref. de	Objet	Quant.	cat.
	cde		Emb.	de prix		cde		Emb.	de prix
Quarz/crystal/quartz					ELEKTRISCHE EINZELTEILE ELECTRICAL SINGLE PARTS ELEMENTS ELECTRIQUES				
Q541,1870	72 2941	4,433619MHz		04					
Q542,1903	72 7719	4,433619 MHz		04					
DIVERSE TEILE DIVERSES PARTS PIECES DIVERSE						75 0802	Verzögerungsleitung GV7 delay line ligne a retard		04
									
72 7699		Mehrfachbuchse multiple socket douille multiple		02	IC670	72 3002	MC14027 BCP		07
72 7700		Batterie/Ni-CD battery batterie		04	IC1015	72 3013	UA 4558 TC		02
72 4300		Kopftrafo head transformer transformateur de tête		07	IC520, 72 7720 1825,1840		TDA 3710		22
75 2143		Schaltnetztrafo transformer (power unit) transformateur (bloc secteur)		24	IC550, } 72 4910 1710 } 72 8352		TDA 3700A oder TDA 3700		24 24
72 4946		Netzschalter power switch interrupteur-secteur		10	IC790	72 3009	TDA 2730		21
72 7764		Sicherungshalter fuse holder porte-fusible		01	IC740	72 8673	TDA 3730		16
72 7765		Schutzkappe protective cap capet de protection		01	IC810	72 8675	TDA 3771		16
72 7766		Ferritperle N 22 ferrite bead perle ferrite		01	IC1215	72 8681	SAB-8051-D31		31
72 7767		Funkstördrossel radio interference suppressor choke self d'antiparasitage		04	IC1225	72 7749	DM 7407		02
72 7220		Knopf f. Modulator knob f. modulator bouton p. modulateur		01	IC1255	72 7750	TL 072 ACP		09
72 7221		Halter f. Knopf holder f. knob support p. bouton		01	IC1265	72 7751	MC14526 BCN/BCP		03
Serviceadapter adapteur service					IC1275, 72 8243 1305		L 272		06
75 2124	"2"			26	IC1350	72 7752	TMS 3716ANL		29
75 2125	"3"			23	IC1360	72 4912	CA 3240 E		07
75 2126	"4"			25	IC1385	72 8244	SB 550		21
					IC1020	72 7761	M14052 BCP		06
					IC1025, 72 3016 2025		TDA 2054 M		07
					IC1060, 72 7762 2060		RC 4156 DB		02
					IC1180, 71 3128 2000		MC 14066 BCP		03
					IC401	72 3178	TDA 4600		10
					IC456	72 2998	MC 1723		03
					IC481	72 7770	7852 Spannungsregler		04
					IC1750	72 3041	TCA 640 A		19
					IC1840, 72 4297 680,1825		MC 14053 BCP		04
					IC1510	75 2142	PCD8571		

SIEMENS

Pos.	Best.-Nr.	Gegenstand	Pckg.	PG	Pos.	Best.-Nr.	Gegenstand	Pckg.	PG
Item	Code No.	Part	Qty.	Price	Item	Code No.	Part	Qty.	Price
			Pckg.	Gp.				Pckg.	Gp.
Pos.	Ref. de	Objet	Quant.	cat.	Pos.	Ref. de	Objet	Quant.	cat.
	cde		Emb.	de prix		cde		Emb.	de prix
									
T505-1961	72 0306	BC 548	2	01	D1027-2093	72 4336	BAS 33		01
T489-1895, 1940	72 4296	BC 558C	2	01	D1084-2091	71 1267	ZPD 6,2		02
T945-1698	72 3063	BC 558 B		01	GL420	72 7773	SKB 380		04
T1925	72 0306	BC 548B T1001-2072	2	01	D402	70 9740	1 N 4007	2	03
T511-1940, 2894	72 3060	BC 548C		01	D1941	72 3092	TD 176		01
T613-2126	72 4911	BC 558		01	D1218	72 3082	1 N 4001		01
T938, 860	72 3062	2 N 5771		01	D1204-1298	72 3032	TD 129		01
T758-939	72 7731	2 N 2369 THO		01	D445	72 4956	BYW 72		02
T1218	72 7754	BC 328-25		02	D481	72 7222	BYW 32		02
T1244	72 3072	BC 549C		01	D486	72 3086	ZPD 33		01
T1334, 1364	72 3077	BF 423		02	D493, 410, 435, 438	72 4953	RGB 10J		01
T1335, 1365	72 7755	BF 422		01	D102	72 7790	BY 601		02
T1336, 1366	72 7756	BF 602		01					
T1337, 1367	72 7757	BF 603		01	TY418	72 7772	MCR 100-7		02
T1092, 2092	71 2167	BC 550C		02					
T1100	72 3064	MPS-A 43		02	R529, 1817	72 7724	0207 NB/100 Ohm		01
T1112, 2100	72 4287	BC 328-40 T2112		02	R2113	72 7486	SKS 1/10 Ohm		02
T1172, 1111, 2111	71 1947	BC 338-40		02	R436	72 7776	2 A/100 Ohm		01
T402	72 4950	BU 208A		10	R772	72 8676	470 Ohm		02
T447	72 7771	BDX 54A		02	R794	72 8677	75 Ohm	2	01
T465, 467, 469, 486	72 3056	BD 534 G		02	R795	72 8678	SKS 2/47 Ohm		02
T485, 487	72 2134	BC 337-40		02	R802	72 8679	100 Ohm	2	01
T101	72 3073	BC 456 B		01	R418	72 8684		2	01
					R436	72 8685			02
D1001-2136	72 3087	TD 018		01	R438	72 5751		2	01
D1509	72 3087	TD 018		01	R466	72 8686		2	01
D1237	72 8254	B2X 75/C1/V4		02	R481	72 5750			02
D1585	72 5888	BZX 83/B4/V7		01	R485	72 8687		2	01
D549-1701-1941	72 3092	TD 176		01	R492	72 8688			02
D591-648, 1936-1947	72 3094	1 N 4154		01					
D859-1775-1911	72 3093	BA 243 G		01	R1331, 1361	72 8683	10 K Ohm		02
					R1858, 1860	72 8670	33 Ohm	2	01
					R1960	72 8062	220 Ohm		02
					R741, 725	72 7733	1 K Ohm		01
					R778, 1842	72 7735	1 K Ohm		01

SIEMENS

Pos.	Best.-Nr.	Gegenstand	Pckg.	PG	Pos.	Best.-Nr.	Gegenstand	Pckg.	PG
Item	Code No.	Part	Qty.	Price	Item	Code No.	Part	Qty.	Price
			Pckg.	Gp.				Pckg.	Gp.
Pos.	Ref. de	Objet	Quant.	cat.	Pos.	Ref. de	Objet	Quant.	cat.
	cde		Emb.	de prix		cde		Emb.	de prix
R1110, 2110	72 7763	100K		01	L401	72 5748	4,7 uH		02
R507, 1890	72 7723	100 K		01	L410	72 7768	470 uH		01
R546, 1708, 1816	72 7725	10 K		01	L431	72 4948			02
R596, 612	72 7726	250 Ohm		01	L445	72 7769			02
R624, 1863	72 7727	1,5 K		01	L1741	72 4962			02
R409	72 7775	2,2 K		01	L1774	72 4961			02
R462	72 5754	500 Ohm		02	L1806	72 7781			01
					L1810/ 11	72 2977			02
L629	72 4908			02	L1812	72 7777			01
L516, 518, 1952, 1954	72 2952			01	L1845	72 7782			02
L521	72 4306			02	L1952, 1954, 1778-1881				02
L557, 559	72 4906			02		72 2964	Drossel 458/120 uH		02
L624 -868, 1858	72 7718			01					
L628, 1863, 1918	72 4909			02		72 7778	Filter LC 2207		02
L1864	72 7708			01	F765	72 8229	Filter 501D-259A		04
L630	72 7778			02		72 7779	Filter LC 2211		03
L701	72 2961			01	F785	72 8228	Filter 1167 A		04
L721, 727,	72 4921			02	F1907	72 7780	5,06 MHz		03
L750, 739	72 7728			01					
L773, 1815	72 2964			02	C1904	72 8669	4,5....20pF		02
L822, 755	72 4920			02	C544, 1871	72 3118	4.....20pF		01
L906, 705	72 4315			02			Bedienungsanleitung Operating instructions Instructions de service		00
L1206	72 8690	6,8 uH		01		53 5096	Service-Druckschrift Service-booklet Brochure service		00
L1398	72 8232			02		73 0426	Satz Kleinteile set small parts jeu pieces miniature		24
L1401	72 7744	820 uH		02			Note: Capacitors and resistors usual in trade are not mentioned in the spare parts list. Kindly buy these parts from the specialized trade.		
L1405, 1407	72 8233			02			Hinweis: Handelsübliche Kondensatoren und Widerstände sind in der Ersatzteil- liste nicht aufgeführt. Wir bitten Sie, diese Teile im Fachhandel zu beziehen.		
L1429, 1399	72 2982			02			Remarque: Les condensateurs et résistances commerciaux ne sont pas mentionnés dans la liste des pièces de rechange. Veuillez acheter ces pièces chez les spécialistes.		
L1434 1396	72 7745			02					
L779,	72 7746	68 uH		01					
L1461	72 8691	68 uH		02					
L1462	72 8692	68 uH		01					
L1036- 2053	72 2974			02					
L1173 2112	72 7760			04					

