




| Gebrauchsanweisung

51 5656
D1,D2,D3,D4,A1
(D)
51 5581
D5
(D,GB,NL,F,E,I,P,GR,
DK,S,N,SF)

1) 05 9489
D1,D4,A1
05 9494
D2,D3
06 6715
D5

2) 05 9466
D1,D4,A1
05 9492
D2,D3
06 6720
D5

Zubehör:

Heizkörperbürste
VZ10092, grau
VZ0683, schwarz

Möbelpinsel
VZ10042, grau
VX0773, schwarz

Turbobürste
VZ47112, grau
VZ470900, schwarz

