




Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
		CD-EINHEITEN	CD-UNIT/unité CD
	75 5059	CD-Einheit komplett	CD-unit complete unité CD complet
	75 4960	Laserabtasteinheit + Mechanik + Motorplatine	pick-up+mechanism+motor p.c.b. unite de laser+mécanisme + circuits imprime p. moteur
		ELEKTRISCHE TEILE	ELECTRICAL PARTS PIECES ELECTRIQUE
		Leiterplatten f. CD-Einheit	printed boards f. CD-unit circuit imprimé p. unité CD
	75 4963	Digital/Analog-Platine	Digital/Analog p.c.b./circuits imprime p. digital-analogique
	75 4964	CD-Disply und Tastenfeld- platine	Display a. keyswitch p.c.b. circuits imprim p. indicator et panneau de touches
LCD002	73 4940	CD-Display	CD-Display
X701	73 4547		
S1	73 4534	Wellenbereich	band/gamme d'ondes
S2	73 4535	Mono/Stereo + Beat cut	
S3	73 4535	Bandsorte	tape select/type de ruban
S4	73 3829	Funktion Radio/Tape	function radio/tape
S5	73 2260	Dubbing	
S6	73 1211	f. Aufnahme/Wiedergabe	f. record-play enregistrement-play back
S7	73 3398	f. Netz	f. power/p. secteur
S8	73 4549	Motorschalter links	leaf switch f. motor
S9	73 4549	Motorschalter rechts	leaf switch f. motor
SW701	73 4548	CD-Endabschaltung	CD-limit/CD-limiteur
SW708	73 4548	f. CD-Fach	f. CD-cover/f. CD-volet
			
VR1	73 2505	Pilotton	pilot
VR201-305	73 3833	Klangregelung	EQ/tonalité
VR206,306	73 3831	Lautstärke	Volume
VR703	73 4550	VCO, CD-Tellerdrehzahl	CD-table speed
VR704,705	73 4551	Spur-Verstärkung/Fokusverst.	track-gain, focus gain
VR706	73 4552	NF-Ausgangspegel	AF-output/level
VR501	73 3419	Drehzahl, Cass.-Motor	motor speed, cass.-motor
			
IC1	73 2503	TA7358AP	
IC2	73 3403	LA1261	
IC3	73 3404	TA7343AP	
IC4	73 3405	M51521AL	
IC5	73 0817	M51164AL	
IC6, 7	73 3406	LA3600	

Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
IC701 IC8 IC702 IC703 IC704 IC705 IC706 IC707,708 IC709 IC801	73 5260 73 2253 73 4539 73 4540 73 4541 73 4542 73 2166 73 4543 72 6138 73 4544	CXA1081M/S AN7148 CXA1082A CXD1130Q CXK5816M15L CXD1140BM NJM4558MT2 BA6290A NJM78L05 CXP5024H038Q	
			
Q501,510 Q101,502 Q702,712 Q703,711	72 8916 71 4604 73 2181 73 2180	2SD1406 2SC1740S DTC124ES DTA124EK	
			
D1,508 D501,504 D505 D2,401	73 3410 70 9579 73 0355 72 8520	1SS133TP 1N4002 UZ9.1B KLR205	
			
BPF LPF1, 2 CF1 CF2 IFT1 IFT2 IFT3 L201,301	73 4537 73 4538 73 0905 73 3417 73 0891 73 3415 73 3416 72 8536	Bandpaß f. UKW-Ant. Eing. f. Pilottonunterdrückung FM-ZF 10.7 MHz AM-ZF 455kHz Filter Filter Filter Sperrkreis	FM-bandpass, antenna input f. pilot FM-IF, 10.7 MHz AM-IF 455kHz
		Buchsen	sockets/douilles
J6 J7 J9 J10	73 3392 73 3786 73 4532 73 3588	US Kopfhörer Netz (AC) Netz (DC)	head phone/récepteur-serre-tête power/secteur power/secteur
			
F	73 4536		
	53 0499	Gebrauchsanweisung	instruction manual instruction d'emploi
	53 5250	Service-Druckschrift	service booklet brochure service







Laufwerk kpl.
mit Lasereinheit
75 5059



Spurführungs-
zahnäder
Tracking gears





°) 73 3842
Satz Federn (I)

*) 73 3920
Satz Federn (II)