






Gebrauchsanweisung
52 8049
(D,GB,ROK)

Montageanleitung
52 8044
(D,GB,ROK)

Befestigungssatz
26 6910





Pos.	V01		
	Danfoss NL7G		
1	14 1774		
2			
3	151055		
4			
5	15 0760		
6	15 1072		
7			
8	35 5493		
9	05 0166		
10			
11	26 6624		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		NL7G		
Förderleistung/Delivery/Débit		l/h	1576	
Anlaufstrom/Starting current/Cour de démarrage		A	15,2	
Widerstand/Resistance/Résistance		Ha/main/prin	Ω	7,3
		Hi/aux	Ω	12,00
Temp.-Regler/Thermostat				
Typ/Type				
Regelstellung/Position				
Schaltwerte/Switching values		"warm"		
Valeurs de commutation		"kalt"		
		"alarm"		
Füllmenge/Fill.quantity/Charge		R134a		
Anschlußwert/Conn.load/Puiss. connectée		W	195	
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
NTC-Fühler / Sensor		°C	kΩ	°C
		+10	9,95 ± 0,18	-18
		+5	12,70 ± 0,18	-22
		0	16,33 ± 0,16	-26
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		