




 Ident - Nummern - Konstante
 3740

 Gebrauchsanweisung
 52 6880
 (D,GB,F,NL)
 52 6931
 (I,E,P,GR,TR)
 Montageanleitung
 52 2772
 (D,GB,F,I,NL,DK,N,SF,S
 E,P,GR,TR)

 Beistellsatz
 18 0744


 1) 360077
 Blende kompl.
 2) 16 8766
 Rep.-Satz



Ident – Nummern – Konstante
3740

1) 15 0693
2) 15 0694
3) 16 5789

Ident – Nummern – Konstante
3740



Pos.	Danfoss NLE15 KTK		
1	14 2111		
2			
3	15 1055		
4			
5	15 0760		
6	15 1072		
7			
8	28 7447		
9	05 0166		
10	15 2222		
11	09 6212		
12	05 6008		
13	35 0026		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		NLE15 KTK		
Förderleistung/Delivery/Débit		2637		
Anlaufstrom/Starting current/Cour de démarrage		A		
Widerstand/Resistance/Résistance		Ω		
Hi/aux		Ω		
Temp.–Regler/Thermostat				
Typ/Type				
Regelstellung/Position				
Schaltwerte/Switching values		"warm"		
Valeurs de commutation		"kalt"		
		"alarm"		
Füllmenge/Fill.quantity/Charge		R600a		
Anschlußwert/Conn.load/Puiss. connectée		W		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
Temp.–Regler/Thermostat		°C	kΩ	°C
		+10	9,95 ±0,18	-18
		+5	12,70 ±0,18	-22
		0	16,33 ±0,16	-26
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		
		1650		
		220		