


**BOSCH**

V360-V360/02-D1
 V360-V360153/02-N1
 V360-V360225/02-F1
 V360-V360/04-D2

V360-V360153/04-N2
 V360-V360225/04-F2

WASCHGERÄTE
 Waschvollautomaten

Ident - Nummern - Konstante
 3740

**Aufstellanweisung**

51 1497
 (D,GB,F,I,NL)
 51 1674
 (D,I,S,DK,N,SF)

Gebrauchsanweisung

51 1496
 (D,GB,F,I,NL)
 51 1690
 (F)
 51 1691
 (D,I,S,DK,N,SF)

Programmtabelle

51 1492
 (D,GB,F,I,NL)
 51 1689
 (D,I,S,DK,N,SF)

- 1) 02 8739
 2) 02 5334
 3) einschl. 05 4644


**BOSCH**

V360-V360/02-D1
 V360-V360153/02-N1
 V360-V360225/02-F1
 V360-V360/04-D2

V360-V360153/04-N2
 V360-V360225/04-F2

WASCHGERÄTE
 Waschvollautomaten

Ident – Nummern – Konstante
 3740






BOSCH


V360-V360/02-D1
V360-V360153/02-N1
V360-V360225/02-F1
V360-V360/04-D2

V360-V360153/04-N2
V360-V360225/04-F2

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740





**BOSCH**

V360-V360/02-D1
V360-V360153/02-N1
V360-V360225/02-F1
V360-V360/04-D2

V360-V360153/04-N2
V360-V360225/04-F2

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740

