




Gebrauchsanweisung



17 4626



17 4627



48 9107

52 4846
de
52 4847
fr
52 4848
gb
52 4849
nl
52 4850
it
52 4851
es
52 4852
sv
52 4853
da
52 4854
no
52 4855
fi
52 4859
pt

Düsensätze/
nozzle sets:

Erdgas E/HG20
20mbar
17 4629
Erdgas LL G25
20mbar
17 6030
Flüssiggas G30/31
28–30mbar
17 4630
Flüssiggas G30/31
50mbar
17 4632

