



Gebrauchsanweisung
51 3623
(D,GB,F,I,NL,DK,N,S,SF)

- 1) 05 1396
rechts
05 1397
links
2) 27 0816
3) 05 6904

Zubehör:

Dekorrahmen
KZ11130SF,gr-br





Pos.	Danfoss		
	TL 5 A		
1	14 0065		
2			
3	05 9191		
4			
5	02 7310		
6	05 1413		
7			
8	11 1919		
9	05 0166		
10			
11	08 4744		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		TL5A		
Förderleistung/Delivery/Débit		l/h	914	
Anlaufstrom/Starting current/Cour de démarrage		A	9,0	
Widerstand/Resistance/Résistance		Ha/main/prin. Ω	15,5	
		Hi/aux Ω	16,8	
Temp.-Regler/Thermostat		M u. J		
Typ/Type		TF57FO		
Reglerstellung/Position		kalt warm		
Schaltwerte/Switching values/ Valeurs de commutation („abtauen“ od.)		„ein“ $^{\circ}\text{C}$	+4	+4
		„aus“	-25	-11
		„alarm“		
Füllmenge/Fill.quantity/Charge		R12	g	90
Anschlußwert/Conn.load/Puiss. connectée		W	110	
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
Schaltuhr/Timer/Minuterie de contact				
Widerstand/Resistance/Résistance		Ω		
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		