




Gebrauchsanleitung
58 1439
(de)

- 1) 29 0341
6KW, V01
29 0342
7KW, V02
29 0343
8KW, V03
29 0344
9KW, V04
- 2) 15 5084
7l/min, V01
16 5874
8l/min, V02
15 5085
9l/min, V03,V04