





51 1423/00
 EU1, F1, GB1
 Gebrauchsanweisung
 (D, GB, F, I, NL, E)



Pos.	EU1,F1,GB1, EU2,F2,GB2			
1	Danfoss			
2	14 0080/44			
3	02 0108/27			
4				
5	02 1361/04			
6	05 1413/06			
7				
8	11 0437/04			
9	05 0166/05			
10				
11	11 1243/01			
12				
13				
14				

TECHNISCHE DATEN / TECHNICAL DATA / DONNÉES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss				
Typ/Type		TL 3 A				
Förderleistung/Delivery/Débit	l/h	576				
Anlaufstrom/Starting current/Cour. de démarrage	A	7,2				
Widerstand/Resistance/Résistance	Ha/main/prin.	Ω	31,7			
	Hi/aux	Ω	17,0			
Temp.-Regler/Thermostat		M + J				
Typ/Type		TF 57				
Reglerstellung/Position		kalt	warm			
Scha. twerte/Switching values/ Valeurs de commutation	„ein“	+ 4	+ 4			
	„aus“	- 25	- 11			
	(„abtauen“ od.)	„alarm“				
Füllmenge/Fill quantity/Charge	R12	g	95			
Anschlußwert/Conn. load/Puiss. connectée		W	90			
Heizung/Heater/Chauffage						
Widerstand/Resistance/Résistance		Ω				
Leistung/Power/Puissance		W				
Ventilator/Blower/Ventilateur						
Widerstand/Resistance/Résistance		Ω				
Magnetventil/Magnetic valve/Electrovanne						
Widerstand/Resistance/Résistance		Ω				
Spannung/Voltage/Tension		V				