

**BOSCH**

EH 562 S — 0 750 031 055—D1 EH 562 S — 0 750 031 088—CH1
— 0 750 031 065—D2
— 0 750 031 087—D3

HERDE
Stand-Herde

Ident-Nummern-Konstante
3740

Gebrauchsanweisung:
51 1607/00
(D, GB, I, F, NL)

Sonderzubehör
Blatt 2

1) 02 2191/01/5





