









0199





| TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS                                                                                                                                                                             |                                    |  |  |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|--|--|
|                                                                                                                                                                                                                                               |                                    |  |  |
| Verdichter/Compressor/Compresseur/Compresor<br>Typ/Type/Tipo<br>Förderleistung/Delivery/Debit/Aspiración l/h<br>Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A<br>Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm<br>Hi/aux. | JIAVIPERA<br>ZBS1114CY<br>TOPPIECE |  |  |
| Klappe Therm./Thermostat/Termostat<br>Typ/Type/Tipo<br>Reglerstellung/Position/Conexión<br>Schaltwerte/Switching values/ ..ein/conex.°C<br>Valeurs de commutation/Desconex. ..aus"/descon.<br>(..abtaven' od) ..alarm'                        | +3.5 , +3.5<br>-31, -20            |  |  |
| Füllmenge/Fill. quantity/Charge/Carga R600 g                                                                                                                                                                                                  | 73                                 |  |  |
| Anschlusswert/Comm. load/Puiss. Connect./Potenc.                                                                                                                                                                                              | W                                  |  |  |
| Heizung/Heater/Chauflage/Resistenc.descong.<br>Widerstand/Resistance/Resistencia<br>Leistung/Power/Puissance/Potencia                                                                                                                         | KW<br>W                            |  |  |
| Ventilador/Blower/Ventilateur/Ventilador<br>Widerstand/Resistance/Resistencia                                                                                                                                                                 | KW                                 |  |  |

\* Siehe Typenschild/Mamul etiketine bakiniz