







0199



0195





| TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS                                                                                                                                                                             |                      |  |  |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|--|--|
| Verdichter/Compressor/Compresseur/Compresor<br>Typ/Type/Tipo<br>Förderleistung/Delivery/Debit/Aspiración l/h<br>Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A<br>Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm<br>Hi/aux. | JIAXIPERA<br>NT1113Y |  |  |
| Klappe Therm./Thermostat/Termostat<br>Typ/Type/Tipo<br>Reglerstellung/Position/Conexión<br>Schaltwerte/Switching values/ ..ein/conex.°C<br>Valeurs de commutation/Desconex. ..aus"/descon.<br>(..abtaven' od) ..alarm'                        |                      |  |  |
| Füllmenge/Fill. quantily/Charge/Carga R600 g                                                                                                                                                                                                  | 100                  |  |  |
| Anschlusswert/Comm. load/Puiss. Connect./Potenc. W                                                                                                                                                                                            |                      |  |  |
| Heizung/Heater/Chauflage/Resistenc.descong.<br>Widerstand/Resistance/Resistencia KW<br>Leistung/Power/Puissance/Potencia W                                                                                                                    |                      |  |  |
| Ventilador/Blower/Ventilateur/Ventilador<br>Widerstand/Resistance/Resistencia KW                                                                                                                                                              |                      |  |  |
| * Siehe Typenschild/Mamul etiketine bakiniz                                                                                                                                                                                                   |                      |  |  |