





07 4445



Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
59 0295
(de,en,fr,it,nl)

Montageanleitung
58 8057

Beistellsatz
26 5163





	V01		
	Aspera		
Pos.	EMY40CLC		
1	14 4134		
2			
3	42 7392		
4			
5	16 9319		
6	17 0881		
7	16 9319		
8	26 4879		
9	0 50166		
10	16 5852		
11	36 5099		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES			
Verdichter/Compressor/Compresseur	Aspera		
Typ/Type	EMY40CLC		
Förderleistung/Delivery/Débit	l/h		
Anlaufstrom/Starting current/Cour de démarrage	A		
Widerstand/Resistance/Résistance	W		
Hi/main/prin	W		
Hi/aux	W		
Temp.–Regler/Thermostat			
Typ/Type			
Regelstellung/Position			
Schaltwerte/Switching values	"warm"		
Valeurs de commutation	"kalt"		
	"alarm"		
Füllmenge/Fill.quantity/Charge	R600a	*	
Anschlußwert/Conn.load/Puiss. connectée	W		
Heizung/Heater/Chauffage			
Widerstand/Resistance/Résistance	W		
Leistung/Power/Puissance	W		
Ventilator/Blower/Ventilateur			
Widerstand/Resistance/Résistance	W		
Temp.–Regler/Thermostat			
Magnetventil/Magnetic valve/Electrovanne			
Widerstand/Resistance/Résistance	W		
Spannung/Voltage/Tension	V		

* siehe Typenschild