






Gebrauchsanweisung
59 1269
(DE,GB,IT,ES,PT)


- 1) 17 2293
- 2) 17 2579
- 3) 42 1602
- 4) 42 4340



- 1) 06 0083
- 2) 17 2274
- 3) 16 5557
- 4) 18 8194
- 5) 18 8188
- 6) 42 0751
- 7) 42 0591



1) 43 2396



TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor		Danfoss	
Typ/Type/Tipo		NLX15KK	
Leistung/Power/Puissance/Potencia	W	181	
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque	A	5,6	
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		11,5	
Hi/aux.		12,7	
Klape Therm./Thermostat/Termostat			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión			
Schaltwerte/Switching values/	..ein/conex. °C		
Valeurs de commutation/Desconex.	..aus"/descon.		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/Charge/Carga	R600	g	65
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	247	
Heizung/Heater/Chauflage/Resistenc.descong.		Verdampfer	Ablaufrinne
Widerstand/Resistance/Resistencia	KW		
Leistung/Power/Puissance/Potencia	W	267	81
Ventilador/Blower/Ventilateur/Ventilador		Verdichter	Verdampfer
Widerstand/Resistance/Resistencia	KW		