




Gebrauchsanweisung
 51 5534
 (D, F, GB, I, NL)

Kochbuch
 51 3874
 (D)


Kochheft
 51 5480
 (D)


Zubehör:

Einbaurahmen kompl.
 Z 6140 B0
 D1, D3
 Z 6140 W0
 D2, D4

Kurzanleitung
 (Speisenaufkleber)
 51 5771
 D1, D2
 51 6451
 D3, D4

Lifftür Glasfront
 Braun
 Z6830B1
 Weiß
 Z6830W2
 Goldbraun
 Z6830G2
 Edelstahl
 Z6830N2
 Schwarz
 Z6830S2





- 1) 03 2869
- 2) 03 2870
- 3) 03 1449