








Libro de instrucciones
51 9303
(es,pt)



1) 09 2939



- 1) 03 3296
- 2) 03 4210
- 3) 03 4104
- 4) 16 2577
- 5) 03 4102
- 6) 03 3957



- 1) 03 3179
- 2) 03 3180
- 3) 03 3181
- 4) 03 3143
- 5) 03 3177
- 6) 06 4545
V02,V03,V04
- 7) 03 4308
V02,V03,V04
- 8) 03 3793
- 9) 15 1525
- 10) 16 2224

Cjtos transformación:
Gas Butano
15 3164
Gas Natural
15 3165
Gas Ciudad
15 3166