






Kullanma kilavuzu
52 3815
(TR)

- 1) 17 3867
- 2) 17 1521
V01
17 6128
V02,V03,V04,V05
- 3) 17 3866
- 4) 35 8634
- 5) 26 8232
V01,V02
26 8570
V03,V04
48 0020
V05
- 6) 35 5042
V01,V02,V03
35 9732
V04,V05
- 7) 17 1522
V01,V02,V03,V04
18 0735
V05
- 8) 35 9845
V05



- 1) 17 3862
- 2) 17 3856
- 3) 17 4593
- 4) 35 5835
- 5) 35 4789
- 6) 17 3850
- 7) 35 5064
V01,V02,V03,V04
36 0399
V05
- 8) 35 5833
V01,V02,V03,V04
36 0407
V05



Pos.	Danfoss		
	NL11F		
1	14 1916		
2	16 5570		
3	35 4583		
4	16 3427		
5	26 5327		
6	17 1318		
7	17 1519		
8	17 2776		
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör		Danfoss	
Typ/Type/Tip		NL11F	
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	A	13.6	
Widerstand/Resistance/Rezistans Ha/	Ω	8.2	
Hi/aux.	Ω	14.7	
Temp.Reyler/Thermostat/Termostat		Elektronisch	
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Actua kapama degerleri	..ein/acma °C		
Valeurs de commutation/Termostat degeri	..aus"/kapama		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantity/ Dolum miktarı		R134a	g
Anschlusswert/Comm. load/Giris gucu		W	*
Heizung/Heater/Rezistans	Ω	Verdampfer	Ablaufrinne
Widerstand/Resistance/Direnc			
Leistung/Power/Guc	W	190	20
Ventilador/Blower/Vantilatör		Verdampfer	
Widerstand/Resistance/Rezistans		Ω	
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans		Ω	
Spannung/Voltage/Gerilim		V	
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakınız