




Mat. - Nr. - Konstante
3740

Gebrauchsanweisung

52 2217-DE
52 2218-GB
52 2219-FR
52 2220-NL
52 2221-ES
52 2223-PT

Kurzanleitung

51 9876
(D)

Montageanleitung

51 6443
(D, GB, F, I, NL, DK, ES,
PT, NO, SE, FI, GR, RU,
CZ, TR, PL)

Kochbuch

51 9787
(D)


Einbausatz

06 8506

1) 15 0043
2) 15 0039
3) 15 0042
4) 15 0038

Zubehör:





Zubehör:

Backblech Email
HZ 24150

Backblech-Auszug
HZ 24250

Universalpfanne
HZ 24350
Grillblech
HZ 22550
Kombirost
HZ 24400
Glasbräter
HZ 9150

