




Gebrauchsanweisung
51 3335
I1,I2
(D,GB,NL,F,I,E,GR,P,
DK,S,SF,N)
51 5661
D1
(D)
51 5565
A1,A2,EU1,EU2
(D,GB,NL,F,I,E,GR,P,
DK,S,SF,N)

Zubehör:

Möbelpinsel
VX 0773
schwarz
Turbobürste
VZ 470900
schwarz
Polieraufsatz
VZ 27 027
grau
Heizkörperbürste
VZ 0683
schwarz
Electromaticbürste
VE 24022/01
schwarz

1) 03 1171
I1,I2,D1
02 8774
A1,A2,D1,EU1,EU2

2) 02 8122
I2
06 8475
A1,A2

1) 05 5543

