




Gebrauchsanweisung
51 6281
D1,D2,D3,D4
(D,GB,NL,F,I,E,P,GR,
S,N,SF)

- 1) 05 4781
- 2) 03 1172
- 3) 06 8566
D1
05 9803
D2,D4
15 0623
D3
- 4) 08 4013
D1,D2,D4
15 0624
D3

Zubehör:

Möbelpinsel
VX0773,schwarz

Heizkörperbürste
VZ0683,schwarz

Turbodüse
VZ470900, schwarz

