




Mat. – Nr. – Konstante	
3740	


Gebrauchsanweisung
58 9523 (de)
V01
58 9533 (de)
V02


58 8240
Infopakett (de)


Montageanweisung
58 6500
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HZ331070
Backblech emailliert
HZ331010
Backblech Antihaft
HZ332070
Universalpfanne
HZ332010
Universalpfanne
Antihaft









- 1) 42 0735
- 2) 42 2811
- 3) 42 2841

