





Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 3849
(IT)

Programmtabelle
58 3850
(IT)



Mat. – Nr. – Konstante
3740

- | | |
|----|---------|
| 1) | 35 5528 |
| 2) | 35 4129 |
| 3) | 26 6751 |
| 4) | 16 8813 |
| | V01 |
| 5) | 18 6869 |
| | V02 |
| 6) | 16 8814 |
| | V01 |
| 7) | 18 6870 |
| | V02 |



Mat. - Nr. - Konstante
3740

1) 26 5964
Set

